



User Manual

CIOT-D20P



www.commax.com COMMAX Co.,Ltd.




- · Thank you for purchasing COMMAX products.
- Please carefully read this User's Guide (in particular, precautions for safety) before using a product and follow instructions to use a product exactly.
- The company is not responsible for any safety accidents caused by abnormal operation of the product.

Contens

- 1. Part Names
- 2. Wiring and Installation
- 3. Package Contents
- 4. Specification




1. Part Names



No.	Contents	No.	Contents
1	MIC	6	Reset button (Press the button for 5 sec, You can initialize status of Camera
2	LED&CDS	_	
3	Camera	7	Contact Port (Door Release)
4	Speaker		
5	Call button	8	PoE



2. Wiring and Installation



- Fix a bracket on a wall with screws
- 2 Connect UTP and Door release cable on the back side of a door camera
- 3 Tighten a screw at the rear side of camera. *Overtightening may cause the O-ring to break.
- 4) Put a Door camera unit into a wall bracket.
- ⑤ Tighten a screw at the top side of a door camera.


* UTP & Contact Port Pin description

1	TX+
2	TX-
3	RX+
4	POE+
5	POE +
6	RX-
7	POE-
8	POE-

No.	Color	Contents
1	Red	VCC 12V
2	Brown	GND
3	Orange	NC(1)
4	Yellow	NO(1)
5	Green	COM(1)
6	Blue	NC(2)
7	Violet	NO(2)
8	White	COM(2)



3. Package Contents





Model Spec	CIOT-D20P	
Wiring	UTP (CAT.5e)	
Voltage	INPUT : PoE DC 36V ~ 54V	
Power Consumption	Standby :3W , Max :10W	
Transmission	Audio : VoIP(SIP Standard)	
Wiring & Distance	UTP (CAT.5e) Standard 70m	
Temperature	-10°C ~ +40°C	
Video	H.264	
Mount Type	Surface	
Angle	90°	
OS	Linux	
Fixel	2Mega Pixel FHD	
Certification	IP67	
Dimension (mm)	59(W) X 164(H) X 42.1(D)	

COMMAX

COMMAX Co.,Ltd.

513-11, Sangdaewon-dong, Jungwon-gu, Seongnam-si, Gyeonggi-do, Korea Int'l Business Dept. : Tel.; +82-31-7393-540~550 Fax.; +82-31-745-2133 Web site : www.commax.com

Edited.2019.12.27